RAZER SNEKI SNEK WALL LIGHT

MASTER GUIDE

Plug in, glow up, and switch it up with the **Razer Sneki Snek Wall Light** – a LED neon gaming light that blazes the way to a more sustainable future. With the sale of each light-saving 10 trees, join us on our #GoGreenWithRazer campaign as we achieve the milestone of 1.25M trees.

CONTENTS

1. WHAT'S INSIDE 3

2. WHAT'S NEEDED 3

3. LET'S GET YOU COVERED 4

4. TECHNICAL SPECIFICATIONS 4

5. GETTING STARTED 5

6. SAFETY AND MAINTENANCE 6

7. LEGALESE 7

1. WHAT'S INSIDE

- Razer Sneki Snek Wall Light



A. LED neon light with RGB lighting
B. USB Type A connector
C. Mounting hole
D. Lighting effect button

- Important Product Information Guide

2. WHAT'S NEEDED

- USB Type A port

Compatible with a 5V USB Type A power source with a minimum current rating of 900mA and above.

3. LET'S GET YOU COVERED

Register your product and score exclusive benefits

razerid.razer.com/warranty



4. TECHNICAL SPECIFICATIONS

- Size: 373 mm / 14.68 in (L) x 311 mm / 12.24 in (W) x 17 mm / 0.67 in (H)
- Weight: 1.3 kg / 2.87 lbs
- Connectivity: USB Type A (5V 900mA and above)
- Switch button placement: Bottom of Sneki Snek
- Material: ABS plastic
- Cable length: 2 m
- Light source: LED

5. GETTING STARTED

SETTING UP THE RAZER SNEKI SNEK WALL LIGHT

Connect the wall light to any of your PC's USB ports.



The wall light is also compatible with a 5V USB Type A power source with a minimum current rating of 900mA and above.

CHANGING THE LIGHTING EFFECT

Press the Lighting effect button to cycle through the effects available in the wall light: Static green (default), Breathing green, Spectrum cycling, and Wave.





6. SAFETY AND MAINTENANCE

SAFETY GUIDELINES

To achieve maximum safety while using your Razer Sneki Snek Wall Light, we suggest that you adopt the following guidelines:

- Don't take apart the device, and don't attempt to operate it under abnormal current loads. Doing so will void your warranty.
- Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for assistance.
- Only use the device indoors. Don't use or install the device near water, moisture, solvents, or other wet surfaces, nor expose it to high temperatures or direct sunlight.
- Make sure only to mount the device on a sturdy hook.
- Keep the device away from liquid, humidity, or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug the device to let its temperature stabilize to an optimal level.

MAINTENANCE AND USE

The Razer Sneki Snek Wall Light requires minimum maintenance to keep it in optimum condition. Once a month, we recommend you unplug the device and clean it using a soft cloth or cotton swab to prevent dirt buildup. Don't use soap or harsh cleaning agents.

7. LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2022 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. or affiliated companies in the United States and other countries. All other trademarks are the property of their respective owners.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer Sneki Snek Wall Light (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.